

# How the RestRoom Stall Block-Aide™ Works



**1** Slide the open end onto the stationary portion of the restroom stall door.



**2** Slide RestRoom Stall Block-Aide™ down so that the center post of the RRSBA goes in the gap between the stationary post & the door so the open area slides down the 2 parts of the restroom stall.



**3** Let it continue to slide down....



**4** ...Until it rests on the door lock/handle.

